



Available online and in the app store:



# Instruction Manual



CE

For use with Breezeboard PRO models:

CLASSIC

VENOM

MONSTER

VENOM  
MONSTER  
FUSION



# Introduction

Congratulations on becoming the proud owner of a Breezeboard PRO. Before you tear up the streets please take the time to read these instructions as it will help to stop you and your Breezeboard PRO shredding big time and keep you looking cool !!!

*Happy  
Breezeboarding  
Everyone!*

Check you have received what you ordered, if not please contact us at:  
[customerservices@breezeboardpro.com](mailto:customerservices@breezeboardpro.com)



*Foot position:*

*Always place your feet in the middle of the foot pads when riding!*

This is the correct riding position and will help you control your board!

# Please Do

- First charge is for 3 hours before your first ride to optimise your battery. (Use the board until the board indicates it needs charging)
- Charge time thereafter is 2 hours each and every time.
- Switch on Breezeboard PRO with both sides set level and on flat ground.
- Both lights on top should light up immediately and then quickly reduce to just one green light on the top of the board. You're now ready to go!
- Learn to ride in a safe place on flat ground and away from obstacles. We recommend holding onto a table or kitchen work surface to learn how to ride and understand how sensitive the board is to your movements.
- Step on one foot at a time, always from the rear of the board while holding on to a table or work surface, try and keep the board level.  
**Riding position: Your feet should always be in the middle of the foot pads!**
- Get off one foot at a time, try and keep the board level and always stepping off to the rear when dismounting your board.
- Stop completely before getting off.
- Ride on even ground and in a safe and responsible manner.
- Be aware of pedestrians, obstacles and uneven ground.
- Keep your Breezeboard PRO clean, dry and free from debris.
- Be patient and take the time to practice before you ride in a congested environment.
- Be considerate to others when using your Breezeboard PRO.
- Use our protective equipment for you and the board  
- you only get one brain !!
- Above all, take your time and **have fun!!!**



# Please Dont



- **DO NOT STAND ON THE MIDDLE SECTION OF THE BOARD EVER!**
- Don't ride through puddles.
- Don't allow untrained riders to ride your Breezeboard PRO without following our basic steps of how to get on the Breezeboard PRO.
- Don't ride in a careless manner as serious injury could occur from misuse or worse you could break your Breezeboard PRO!
- Don't remove casing or attempt repair as it will invalidate your warranty.
- Don't ride on sand or mud, it wont handle and we don't advise it.
- Don't ride at full speed for prolonged periods as this can make it difficult for the Breezeboard PRO to maintain balance as well as cause unnecessary strain on the Breezeboard PRO components as well as risk your safety. It is not designed for high speeds.
- **VERY IMPORTANT**  
**DO NOT LEAVE CHARGING WHEN CHARGER LIGHT GOES GREEN!**  
**PROLONGED CHARGING WILL DAMAGE THE LIFE OF YOUR BATTERY.**  
**PROLONGED CHARGING INVALIDATES BATTERY WARRANTY.**  
**ONLY CHARGE WHILE THIS LIGHT IS RED, 2 HOURS MAXIMUM CHARGING.**

*Very  
Important!*

**DO NOT USE A THIRD  
PARTY POWER SUPPLY.**





# The Bluetooth Speaker

*For your listening pleasure*



## If you went for the Bluetooth option, BOOM!

Ok, so that's the boring stuff out the way, now lets get started: after switching on the Breezeboard PRO. You will hear a voice saying "bluetooth ready". Have your bluetooth device ready, let's say you are trying to connect the bluetooth on your phone to the Breezeboard PRO. Check your phone has bluetooth switched on. Use your phone to search for new devices and the Breezeboard PRO should appear as code "JJKJ" or similar. Once it has recognised and connected the Breezeboard PRO will audibly confirm connection has been made.... Simples!! Now select the music you want to listen to and boom!! You can blast out your tunes, your volume is controlled from your bluetooth device.

# Getting Started

So your now ready to get moving. Get on one foot at a time from behind the Breezeboard PRO and always get off the rear one foot at a time. First of all use the Breezeboard PRO using just one foot i.e. one foot on Breezeboard PRO one on the ground. Just to feel the movement of the Breezeboard PRO. Tip foot forward and feel the Breezeboard PRO move forward. Tip foot backwards and feel the Breezeboard PRO move backwards. Master the Breezeboard PRO moving back and forth before trying both feet. The Breezeboard PRO is incredibly sensitive, slight movements are all that is needed for the board to react.

## First time on a Breezeboard PRO?

OK, hold on to something i.e. to a person or a fixed object say try holding on to a kitchen work surface. Once on with both feet stand still and allow Breezeboard PRO to balance before you move. The secret to your success is to make sure you can stand still on a Breezeboard PRO.

Now lean slightly forward and press lightly on the front of the pedals and you will start to move forward. Drop your heels and therefore the opposite applies you will move backwards. Just try to move forward and backward while holding on.

To rotate the Breezeboard PRO press one pedal forward and one backwards whilst taking care to stay balanced on the Breezeboard PRO. Try moving forward slowly now. Keep holding on to someone's hand till your confidence grows. With a bit of patience and practice you will master it in no time. Most people can start moving with confidence in under an hour, some people pick it up in just 5 minutes.

## Battery

The battery in the Breezeboard PRO is a Samsung cell or LG cell battery pack and is of the highest quality available. When new it may take up to twenty re-charge cycles for it to reach its full capacity, we recommend using and recharging fully each time, do not leave charging overnight.



*Be very careful,  
and take your time*



# Recalibration

## How do I reset or rebalance my board?

The Breezeboard PRO from time to time needs a reset, this is easy to do:

1. Charge the Breezeboard PRO for two hours.  
(The charger has a red light on it which illuminates when plugged in, this red light will turn to green when fully charged.) Then unplug the charger.
2. Turn off the Breezeboard PRO and make sure the tops of both sides of the boards are level. If its working fine both lights should light up quickly and then reduce to just one green light on the top of the board.
3. Turn off the board.
4. Hold down the "on" button for 30 seconds. The blue lights should come on under the Breezeboard PRO and start flashing. Let them continue for 30 seconds.
5. Turn off the Breezeboard PRO.  
FINALLY - Turn it back on again two green lights then one on the top?  
YOU'RE GOOD TO GO! HAPPY BREEZEBOARDING

Not Green? Email: [customerservices@breezeboardpro.com](mailto:customerservices@breezeboardpro.com)

## How do I use the Keyfob?

The remote control is the key fob in the box. Although this has four buttons it's used for just turning the board on and off remotely. Alternatively, if you prefer you can use the silver on/off button on the side of the Breezeboard PRO. The other buttons are redundant and have no functionality.

### TO PAIR THE KEYFOB TO YOUR BOARD:

When the board is turned on, turn it off with your keyfob, this will pair it to your board. From then on you will be able to turn it on and off remotely.


**DO NOT TURN THE BOARD OFF WITH KEY FOB WHEN BOARD IS MOUNTED.**



# Technical Specification

Battery	High Powered Li-On Samsung or LG (Cells) 20 Series 36V 4.4AH 158WH
Power Required	AC 100-240v / 50-60Hz
Charging Voltage	42V
Speed	10 - 15 kmh (Depending on usage)
Range	15-20km (Depending on usage)
Motor	Brushless 2 x 350w (350w)
Charge Time	2 hours maximum
Maximum Load	200kg
Minimum Load	10kg
Wheel	Classic & Venom - Inflation Free 6.5" tyre Monster & Fusion - Inflated 10" tyre (35psi)
MaxGradient Ability	16°
Warranty	12 months battery and charger
Net Weight	Classic & Venom - 10kg Monster & Fusion - 20kg
Gross Weight	Classic & Venom - 12kg Monster & Fusion - 22kg
Turn Radius	0°
Ground Clearance	Classic & Venom - 30mm Monster & Fusion - 50mm
Platform Height	Classic & Venom - 110mm Monster & Fusion - 145mm
Speed Protection	Tilts when reached 10km
Storage Conditions	0°C to 50°C
Usage Temperature	-10°C to 40°C
Waterproof & dustproof level	IP54





This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Please read our Do's and Don'ts pages. Small children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Breezeboard PRO boards are ONLY to be used with the power supply unit provided.


Breezeboard PRO boards must only be used at the extra low voltage corresponding to the marking on the product. **DO NOT USE A THIRD PARTY POWER SUPPLY.**

Do not charge for more than 2 hours, doing so could harm your battery performance.



CE Marking on a product is a manufacturer's declaration that the product complies with the essential requirements of the relevant European health, safety and environmental protection legislation, in practice by many of the so-called Product Directives.\*

\*Product Directives contains the "essential requirements" and/or "performance levels" and "Harmonized Standards" to which the products must conform. Harmonized Standards are the technical specifications (European Standards or Harmonization Documents) which are established by several European standards agencies (CEN, CENELEC, etc). CEN stands for European Committee for Standardization. CENELEC stands for European Committee for Electrotechnical Standardization.



The WEEE Directive (Waste from Electrical and Electronic Equipment Directive) 2002/96/EC uses a special logo in addition to the CE logo to show that the equipment should not be disposed of in the normal waste stream.

The purpose of the WEEE Directive is, as a first priority, the prevention of waste electrical and electronic equipment (WEEE), and in addition, the reuse, recycling and other forms of recovery of such wastes so as to reduce the disposal of waste. It also seeks to improve the environmental performance of all operators involved in the life cycle of electrical and electronic equipment, e.g. producers, distributors and consumers and in particular those operators directly involved in the treatment of waste electrical and electronic equipment.



# Broken Board?

PLEASE CALL THE DOCTOR ON  
01925 909140

He will be happy to guide you through any issues, but first, please make sure you have charged your Breezeboard PRO up fully and have recalibrated the board as described on page 7 of this manual. This may well fix any issue.

## RETURNS

### What is your returns policy?

If you are unhappy with product, we will allow you to return the item within 30 days, as long as the board is in pristine condition! - we have a no quibble 30 day returns policy.

### What happens if the Breezeboard PRO breaks?

We warranty the battery and charger for 12 months, due to the nature of the product we can't be held responsible for breakages. If the Breezeboard PRO breaks, which is very rare indeed, we can fix it for you at our repair centre, but you will be charged accordingly for the parts and labour.

## SHIPPING

### How long does shipping take?

We find that orders are dispatched within 2 -3 business days. However, if the model is unavailable we will call you to offer an alternative, in exceptional circumstances delivery can take upto 14 days.

### Will I be charged for taxes?

No. The taxes are included in your overall cost.

### Which company do you use for shipping?

We currently use DPD, Interlink and Yodel for shipping our Breezeboard PROs.

## PAYMENT & WARRANTY

### What forms of payments do you accept?

We currently accept payment online via our merchant Klarna, you can contact them at [www.klarna.com](http://www.klarna.com)

### What are your warranty terms & conditions?

The battery, charger and charging port are guaranteed for a period of 1 year.

## WHAT IS THE ADDRESS FOR COMPLAINTS

Please put any complaints in writing, to  
Breezeboard PRO Swegway Superstore  
Unit 4, within the Chillfactor  
Trafford Quays Leisure Village  
Trafford Way, Manchester M41 7JA

GOT ANY FURTHER QUESTIONS? Please email us on [customerservices@breezeboardpro.com](mailto:customerservices@breezeboardpro.com) or via our social media channels.

# Download the APP!




Search “Breezeboard PRO”


- NEW PRODUCTS
- INSTRUCTION MANUAL
- LEARN TO RIDE FEATURE
- TIPS N TRICKS
- THE DOCTOR SERVICE
- HANDY CHARGING TIMER FEATURE
- SPECIAL OFFERS AND DISCOUNTS

EXCLUSIVE  
ACCESS TO GREAT  
ONLINE DEALS  
ONLY AVAILABLE  
TO OUR APP  
USERS





Download our manual at our website or get our handy app!



[www.breezeboardpro.com](http://www.breezeboardpro.com)